



## RDF310.2/MM


### Mounting Location of Thermostat / 温控器安装位置




### Preparation and Deliverables / 安装前准备




### Flush-Mounting / 嵌入式安装







## Wiring Diagrams / 接线图



⚠ L-N, Y11/Y12 AC 230 V



⚠ L-N, Y11/Y12 AC 230 V



⚠ L-N, Y11/Y12 AC 230 V

**en**

Legend / 图例:

N1 RDF310.2/MM

M1 3-speed fan

V1 Valve

V2 SUA21/1

C1 Compressor

⚠ Power supply is AC 230 V

⚠ Y12 cannot be used as power supply of AC 230 V

⚠ Do not connect Y12 to either L or N from the mains or AC 230 V power supply

**zh**

RDF310.2/MM

三速风机

阀门

SUA21/1

压缩机


电源电压为 AC 230 V

Y12 不能用作 AC 230 V 电源

请勿将 Y12 接到主电源或 AC 230 V 电源的零线或火线上

## Dimensions / 尺寸

View / 视图 A



View / 视图 B

